


RENAULT MASTER Electric



All types (2022 -)







	Airbag		Stored gas inflator		Seat belt pretensioner	SRS control unit		Pedestrian protection active system
	Automatic rollover protection system		Gas strut / Preloaded spring		High strength zone	Zone requiring special attention		
000 000	Battery low voltage	HH	Ultra- capacitor, low- voltage		Fuel tank	Gas tank		Safety valve
0 0	Battery pack, high-voltage	2	High voltage power cable	0	High voltage device that disconnects high voltage	Fuse box disabling high voltage	4	High voltage ultra- capacitor



Internal reference	Version date	Version	Page
RS-X62 EV-2022	14/01/2022	1	1 / 4

1. Identification / recognition




2. Immobilisation / stabilisation / lifting

Engine shutdown



Forbidden wedge area



Orange 400V cables area


3. Disable direct hazards / safety regulations

12 Volts Battery




1- Remove the screws





2 - Disconnect the negative terminal (-)



In consultation with




Internal reference	Version date	Version	Page
RS-X62 EV-2022	14/01/2022	1	2 / 4

400 Volts battery




Only if cutting operation is necessary:


Disconnection of the 400 Volts battery by removing the service plug.



4. Access to the occupants

HARDENED STEEL





5. Stored energy / liquids / gases / solids



Lithium-ion

52 kW.h

400 V




In consultation with
Liberal - Égalité - Fraternial RÉPUBLIQUE FRANÇAISE
MINISTÈRE DE L'INTÉRIEUR

Internal reference	Version date	Version	Page
RS-X62 EV-2022	14/01/2022	1	3 / 4

6. In case of fire

Extinguishing a traction battery fire propagation









If traction battery on fire : → Water extinguishing by filling

7. In case of submersion





No electrical hazard

8. Towing / transportation / storage



10. Explanation of pictograms used

4	Electri	c Vehicle		Bonnet		
☐IR ∭	Use thermal Infrared camera		J. EV	Special battery access		
Electrical protection gloves	Face shield	Breathing apparatus (BA)	Use water to extinguish the fire	Don't brake, nor open		
				\otimes		

In consultation with
Liberet - Égaliste - Fraternist RÉPUBLIQUE FRANCAISE
MINISTÈRE DE L'INTÉRIEUR

Internal reference	Version date	Version	Page
RS-X62 EV-2022	14/01/2022	1	4 / 4